

Battery Charger Safety Instructions

MODEL: RK 20001 INPUT: 100-240Vac 50/60Hz,2A

OUTPUT: 21V== 4A

DEAD WEIGHT: 300g DIMENSIONS: 116x86x66mm

To ensure safe and efficient use of the battery charger, please follow these safety instructions carefully.

⚠ WARNING: ELECTRIC SHOCK HAZARD

Keep the charger away from water and moisture.
Do not touch the charger with wet hands.

⚠ WARNING: FIRE HAZARD

Use the charger only in well-ventilated areas.
Avoid using with damaged cords or plugs.

**⚠ WARNING: CHARGE ONLY GRABO TB21000 20V/
TB31000 18V LITHIUM BATTERY**

⚠ CAUTION: FOR INDOOR USE ONLY

GENERAL SAFETY

- Always unplug the charger when not in use.
- Ensure the charger is on a stable, flat surface during use.
- Do not attempt to use the charger with non-rechargeable batteries.

i You can easily download the manual by visiting
<https://grabo.com/products/grabo-high-flow/>

USAGE GUIDELINES

- Connect the charger to the battery before plugging into an outlet.
- Disconnect from the outlet before removing the battery.
- Children shall not play with the appliance.
- This appliance is designed for indoor use only.
- Cleaning and tool maintenance shall not be made by children without supervision.
- This appliance can be used by children aged 8 and older, as well as individuals with physical, sensory, or cognitive impairments, or those lacking experience and knowledge, provided they receive proper supervision or instruction on its safe use and understand the associated hazards.

For future assistance, contact our customer service:

Phone: +1 (844) 430-0510

Email: Info@GRABO.com

Manufacturer's Address:

Shenzhen WOTY energy CO.,LTD, Floor 4, Building C,
Zhengchangda Digital Electronics Factory,
Jian 'an Road, Tangwei Community, Fuhai Street,
Bao 'an District, Shenzhen, Guangdong, China